# QuiltMotion Quick Start Guide
How To Place and Sew a Design


"Click on" "Select & Sew" to set your "Safe Area"
and open the "Power Placement" screen.

Place and Sew a Design continued. . .

You will now be prompted to set the Safe Area Width and Depth.

OK

Select & Sew Power Placement Depth (the Depth of your "Machine Throat" if you are putting the size in manually.

The "Safe Area" is your "quiltable," quilting area on your quilt top. Move your machine to the "TOP LEFT of your Quilt Top corner (edge) and tap on the screen in the "Click to Set the Safe Area." You have now set your "Safe Area" WIDTH. "STOP" Read next page.

Toolbox <

Ruler
Marking Tool
Set Safe Area

Show Pattern Size
Show Placement Nodes

Click to Set
the Safe Area

Multi-Placement
Pattern
Ditch
Markings

Quilt

Place and Sew a Design continued. . .

Safe Area Select & Sew Power Placement

Depth of Machine Throat

throat

Safe Area

Width

You will now be prompted to set the Safe Area Width and Depth.

OK

*Note: Select & Sew Power Placement Depth (the Depth of your "Machine Throat" if you are putting the size in manually.

"Safe Area" "DEPTH" is your "quiltable," quilting area determined by the arm (throat length) of your machine. Move your machine the width of the quilt top to the right top edge, then move the machine as far forward as you can towards the front of the frame as far forward as the machine will extend, keeping it on the right edge of your quilt to the "BOTTOM RIGHT" of your Quilt Top (edge) and tap on the screen.

Toolbox <

Ruler
Marking Tool
Set Safe Area

Show Pattern Size
Show Placement Nodes

Click to Set
the Safe Area

Multi-Placement
Pattern
Ditch
Markings

Quilt

Place and Sew a Design continued. . .

This is your "Read Pattern" screen, here you can choose different designs such as:

- Pattern Design (Purchased Designs)
- Block Design
- Continuous Line Design
- Triangle Design
- Border Sets Designs

Use the arrows on the right to scroll up and down through the design choices. To select a design, tap on it, a blue box will show that it has been selected. Now click on "Open" to open your "Pattern Placement" screen.

Place and Sew a Design continued. . .

Find the "Placements" using the arrows to the right find "Block" with "Block" placement you will have two placement nodes (gray dots around design). One is at the top left of the design and one at the bottom right. Using these placement nodes we will place our design in the area on our quilt we want it quilted.

Place and Sew a Design continued. . .


Node is green

New position

Move your sewing machine to the first placement point on your quilt. I have chosen the top left corner of my block on my quilt. Tap on the top left placement node of your design, your design will now move on the tablet screen to the position as to where you moved your machine on your quilt.

Place and Sew a Design continued. . .

Move your machine to your 2nd placement, I have chosen the bottom right corner of my block on my quilt. Tap on your bottom right node and once you have placed it the node will turn from gray to green.

Place and Sew a Design continued. . .

Once you have placed your design, we can click on "Quilt," this will take us to our "Quilting Interface" screen.

Place and Sew a Design continued. . .

Start point and end point of design

Power Placement - Fixed
The pattern is placed and ready to sew.

Sew

Repair Pattern

Trace

Pull Bobbin

Back

| Placement	Power
Fill Method	Placement
Sew Speed	Medium
Stitch per Inch	10
Placed Height	6.672
Placed Width	11.822

Click on "Pull Bobbin" your machine will engage with the automation, slightly moving just a bit a prompt will show on your screen to make sure your needle is in the up position. Click "OK" after making sure the needle is up, your machine will move to where your design will start quilting on your quilt block.

Place and Sew a Design continued. . .


Start point and end point of design

Once the machine has moved to where it will start sewing, your needle will automatically go down into the fabric to catch your bobbin thread. After it has finished going down into your fabric you will see the prompt again asking if your needle is up. Click "OK."

Place and Sew a Design continued. . .

Start point and end point of design

Power Placement – Fixed					
The pattern is placed and ready to sew.	**Sew**	Repair Pattern	Placement	Power	
			Fill Method	Placement	
		Trace Pull Bobbin	Sew Speed	Medium	
			Stitch per Inch	10	
		◀ **Back**	Placed Height	6.672	
			Placed Width	11.822	

The sewing machine will move away from the start point pulling your bobbin thread up to the top of your quilt. Once the bobbin thread has been pulled click on "SEW." The sewing machine will move back to your start point of your design and do a stitch tie off and start sewing your design on to your quilt block.

Place and Sew a Design continued. . .

Click on "Finished!" pull your machine to the side of your design, to give some length to your bobbin thread. Move your machine back to where you ended quilting and click on your needle down button or tap on your needle down on your machine screen. Bring your needle back up and with it your bobbin thread. Cut both threads and proceed on to place your next design.